

MAZDA OIL Function List(Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Model	OIL
ATENZA	※
CAROL/FLAIR WAGON/SCRUM/FLAIR	※
CX-3	※
CX-5	※
CX-8	※
CX-9	※
DEMIO (JPN) / VERISA (JPN) / MAZDA2 (General)	※
DEMIO / 121 DEMIO / 121	※
DEMIO / FESTIVA MINI WAGON	※
FAMILIA / LASER	※
MAZDA2 / DEMIO	※
MAZDA3 / AXELA	※
MAZDA3/ AXELA	※
MAZDA6 / ATENZA	※
MAZDA6/ ATENZA	※
MPV (North America / General)	※
MX-5	※
MX-5 / ROADSTER	※
MX-5 MIATA	※
Millenia	※
PREMACY	※
PROTEGE	※
Titan	※
XEDOS9	※

OIL Function List

Engine Oil Maintenance Monitor Change Setting

Engine Oil Maintenance Monitor Remain Oil Life

Oil Remainder Reset

Setting Change Of Oil Remainder

MAZDA SAS Function List(Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Model	SAS
DEMIO (JPN) / MAZDA2 (General)	※
DEMIO (JPN) / MAZDA2 (OTHER)	※
Escape /Tribute / Mariner	※
MAZDA2 (China)	※
MAZDA2 (Europe)	※

SAS Function List

Configure The Steering Angle Sensor

Steering Angle Calibration

Steering Torque Sensor Trim

Steering Wheel Position Sensor Calibration

MAZDA TPM Function List(Not:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Model	TPM
AXELA / MAZDA3	※
CX-3	※
CX-4	※
CX-5	※
CX-7 (Europe / General Specs.)	※
CX-7 (North America / General Specs.)	※
CX-9	※
CX-9 (North America / General Specs.)	※
DEMIO (JPN) / MAZDA2 (OTHER)	※
DEMIO (JPN) / VERISA (JPN) / MAZDA2 (General)	※
DEMIO / 121 DEMIO / 121	※
DEMIO / FESTIVA MINI WAGON	※
FAMILIA / LASER	※
MAZDA2 / DEMIO	※
MAZDA3 (North America / General)	※
MAZDA3 / AXELA	※
MAZDA3/ AXELA	※
MAZDA5 (North America Specs.)	※
MAZDA6 (GH, After Facelift) / ATENZA	※
MAZDA6 (GH, Before Facelift)	※
MAZDA6 (Middle East / General)	※
MAZDA6 (North America / General)	※
MAZDA6 / ATENZA	※
MAZDA6/ ATENZA	※
MPV (North America / General)	※
MX-5	※
MX-5 (Europe / General Specs.)	※
MX-5 (North America / General Specs.)	※
MX-5 / ROADSTER	※
MX-5 MIATA	※
Millenia	※
PREMACY	※
PREMACY / MAZDA5	※
PROTEGE	※
RX-8 (North America Specs.)	※
Ranger / Mazda B-Series / Troller	※
Titan	※
XEDOS9	※

TPM Function List

TPMS (Tire Pressure Monitoring System) Functions

TPMS (Tire Pressure Monitoring System) Reset

TPMS (Tire Pressure Monitoring System) Sensor Training Mode

MAZDA BLD Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Model	BLD
(All MY05) Escape/Tribute/Maverick/Mariner	※
AXELA (Hybrid)	※
CX-9 (North America / General Specs.)	※
Escape / Tribute / Maverick	※
Ranger / Mazda B-Series / Troller	※

BLD Function List

ABS Service Bleed

Air Bleeding

MAZDA BMS Function List(Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Model	BMS
Ranger / Mazda B-Series / Troller	※
BMS Function List	
BMS Reset	

MAZDA Diagnostic Function List (Note: For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Model	Year	System	EcuInfo.	ReadCode	EraseCode	LiveData	ActTest
ATENZA	ALL	PCM	●	●	●	●	※
ATENZA	ALL	TCM	●	●	●	●	※
ATENZA	ALL	ABS	●	●	●	●	※
ATENZA	ALL	RCM	●	●	●	●	※
ATENZA	ALL	IC	●	●	●	●	※
ATENZA	ALL	EATC	●	●	●	●	※
ATENZA	ALL	EPB	●	●	●	●	※
ATENZA	ALL	SCBS	●	●	●	●	※
ATENZA	ALL	AFS	●	●	●	●	※
ATENZA	ALL	AM	●	●	●	●	※
ATENZA	ALL	DSM	●	●	●	●	※
ATENZA	ALL	EPS	●	●	●	●	※
ATENZA (JPN) / MAZDA6 (General)	2002-2007	PCM	●	●	●	●	※
ATENZA (JPN) / MAZDA6 (General)	2002-2007	TCM	●	●	●	●	※
ATENZA (JPN) / MAZDA6 (General)	2002-2007	ABS	●	●	●	●	※
ATENZA (JPN) / MAZDA6 (General)	2002-2007	RCM	●	●	●	●	※
ATENZA (JPN) / MAZDA6 (General)	2002-2007	IC	●	●	●	●	※
ATENZA (JPN) / MAZDA6 (General)	2002-2007	EATC	●	●	●	●	※
ATENZA (JPN) / MAZDA6 (General)	2002-2007	BCM	●	●	●	●	※
ATENZA (JPN) / MAZDA6 (General)	2002-2007	EPS	●	●	●	●	※
AXELA (Hybrid)	ALL	PCM	●	●	●	●	※
AXELA (Hybrid)	ALL	RCM	●	●	●	●	※
AXELA (Hybrid)	ALL	IC	●	●	●	●	※
AXELA (Hybrid)	ALL	EATC	●	●	●	●	※
AXELA (Hybrid)	ALL	HV-ECU	●	●	●	●	※
AXELA (Hybrid)	ALL	AFS	●	●	●	●	※
AXELA (Hybrid)	ALL	EPS	●	●	●	●	※
AXELA (Hybrid)	ALL	BCM	●	●	●	●	※
AXELA/MAZDA3	ALL	PCM	●	●	●	●	※
AXELA/MAZDA3	ALL	TCM	●	●	●	●	※
AXELA/MAZDA3	ALL	ABS	●	●	●	●	※
AXELA/MAZDA3	ALL	RCM	●	●	●	●	※
AXELA/MAZDA3	ALL	IC	●	●	●	●	※
AXELA/MAZDA3	ALL	EATC	●	●	●	●	※
AXELA/MAZDA3	ALL	BCM	●	●	●	●	※
AXELA/MAZDA3	ALL	EPS	●	●	●	●	※
AXELA/MAZDA3 (Japan/General Specs.)	2003-2006	PCM	●	●	●	●	※
AXELA/MAZDA3 (Japan/General Specs.)	2003-2006	TCM	●	●	●	●	※
AXELA/MAZDA3 (Japan/General Specs.)	2003-2006	ABS	●	●	●	●	※
AXELA/MAZDA3 (Japan/General Specs.)	2003-2006	RCM	●	●	●	●	※
AXELA/MAZDA3 (Japan/General Specs.)	2003-2006	IC	●	●	●	●	※
AXELA/MAZDA3 (Japan/General Specs.)	2003-2006	EATC	●	●	●	●	※
AXELA/MAZDA3 (Japan/General Specs.)	2003-2006	EPS	●	●	●	●	※
AXELA/MAZDA3 (Japan/General Specs.)	2003-2006	GEM	●	●	●	●	※
AXELA/MAZDA3 (Japan/General Specs.)	2003-2006	RKE	●	●	●	●	※
AZ-OFFROAD	1999-2008	PCM	●	●	●	●	※
AZ-OFFROAD	1999-2008	TCM	●	●	●	●	※
AZ-OFFROAD	1999-2008	ABS	●	●	●	●	※
AZ-OFFROAD	1999-2008	RCM	●	●	●	●	※
AZ-WAGON (MD/MJ) / SPIANO (HF)	1998-2001	PCM	●	●	●	●	※
AZ-WAGON (MD/MJ) / SPIANO (HF)	1998-2001	ABS	●	●	●	●	※
AZ-WAGON (MD/MJ) / SPIANO (HF)	1998-2001	RCM	●	●	●	●	※
AZ-WAGON (MJ)	2003-2006	PCM	●	●	●	●	※
AZ-WAGON (MJ)	2003-2006	ABS	●	●	●	●	※
AZ-WAGON (MJ)	2003-2006	RCM	●	●	●	●	※
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/ FLAIR WAGON/FLAIR	ALL	PCM	●	●	●	●	※
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/ FLAIR WAGON/FLAIR	ALL	TCM	●	●	●	●	※
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/ FLAIR WAGON/FLAIR	ALL	ABS	●	●	●	●	※

AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/ FLAIR WAGON/FLAIR	ALL	RCM	●	●	●	●	※
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/ FLAIR WAGON/FLAIR	ALL	IC	●	●	●	●	※
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/ FLAIR WAGON/FLAIR	ALL	EATC	●	●	●	●	※
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/ FLAIR WAGON/FLAIR	ALL	BCM	●	●	●	●	※
AZ-WAGON/CAROL/SCRUM/AZ-OFFROAD/ FLAIR WAGON/FLAIR	ALL	EPS	●	●	●	●	※
Biante (Japan)	2008-2012	PCM	●	●	●	●	※
Biante (Japan)	2008-2012	TCM	●	●	●	●	※
Biante (Japan)	2008-2012	ABS	●	●	●	●	※
Biante (Japan)	2008-2012	RCM	●	●	●	●	※
Biante (Japan)	2008-2012	IC	●	●	●	●	※
Biante (Japan)	2008-2012	EATC	●	●	●	●	※
Biante (Japan)	2008-2012	EPS	●	●	●	●	※
Biante (Japan)	2008-2012	GEM	●	●	●	●	※
BONGO/BONGO BRAUNY/SPECTRON	1999-2016	PCM	●	●	●	●	※
BONGO/BONGO BRAUNY/SPECTRON	1999-2016	TCM	●	●	●	●	※
BONGO/BONGO BRAUNY/SPECTRON	1999-2016	ABS	●	●	●	●	※
BONGO/BONGO BRAUNY/SPECTRON	1999-2016	IC	●	●	●	●	※
BONGO BRAUNY/ECONOVAN/MAZDA E-SERIES	1996-2002	PCM	●	●	●	●	※
BONGO BRAUNY/ECONOVAN/MAZDA E-SERIES	1996-2002	TCM	●	●	●	●	※
BONGO BRAUNY/ECONOVAN/MAZDA E-SERIES	1996-2002	ABS	●	●	●	●	※
BT-50/Ranger	2007	PCM	●	●	●	●	※
BT-50/Ranger	2007	ABS	●	●	●	●	※
BT-50/Ranger	2007	RCM	●	●	●	●	※
BT-50/Ranger	2007	ESOF	●	●	●	●	※
CAPELLA/CAPELLA W/TELSTAR/TELSTAR W	1997-1999	PCM	●	●	●	●	※
CAPELLA/CAPELLA W/TELSTAR/TELSTAR W	1997-1999	ABS	●	●	●	●	※
CAROL	1998-2004	PCM	●	●	●	●	※
CAROL	1998-2004	ABS	●	●	●	●	※
CAROL	1998-2004	RCM	●	●	●	●	※
CAROL/FLAIR WAGON/SCRUM/FLAIR	ALL	PCM	●	●	●	●	※
CAROL/FLAIR WAGON/SCRUM/FLAIR	ALL	ABS	●	●	●	●	※
CAROL/FLAIR WAGON/SCRUM/FLAIR	ALL	RCM	●	●	●	●	※
CAROL/FLAIR WAGON/SCRUM/FLAIR	ALL	IC	●	●	●	●	※
CAROL/FLAIR WAGON/SCRUM/FLAIR	ALL	EPS	●	●	●	●	※
CX-3	ALL	PCM	●	●	●	●	※
CX-3	ALL	TCM	●	●	●	●	※
CX-3	ALL	4X4	●	●	●	●	※
CX-3	ALL	ABS	●	●	●	●	※
CX-3	ALL	RCM	●	●	●	●	※
CX-3	ALL	IC	●	●	●	●	※
CX-3	ALL	EATC	●	●	●	●	※
CX-3	ALL	AFS	●	●	●	●	※
CX-3	ALL	BCMII	●	●	●	●	※
CX-3	ALL	EPS	●	●	●	●	※
CX-4	ALL	PCM	●	●	●	●	※
CX-4	ALL	TCM	●	●	●	●	※
CX-4	ALL	4X4	●	●	●	●	※
CX-4	ALL	ABS	●	●	●	●	※
CX-4	ALL	RCM	●	●	●	●	※
CX-4	ALL	IC	●	●	●	●	※
CX-4	ALL	EPB	●	●	●	●	※
CX-4	ALL	EATC	●	●	●	●	※
CX-4	ALL	AFS	●	●	●	●	※
CX-4	ALL	BCMII	●	●	●	●	※
CX-4	ALL	EPS	●	●	●	●	※
CX-5	ALL	PCM	●	●	●	●	※
CX-5	ALL	TCM	●	●	●	●	※
CX-5	ALL	4X4	●	●	●	●	※
CX-5	ALL	ABS	●	●	●	●	※
CX-5	ALL	RCM	●	●	●	●	※
CX-5	ALL	IC	●	●	●	●	※
CX-5	ALL	EPB	●	●	●	●	※
CX-5	ALL	EATC	●	●	●	●	※
CX-5	ALL	AFS	●	●	●	●	※
CX-5	ALL	BCMII	●	●	●	●	※
CX-5	ALL	EPS	●	●	●	●	※

CX-7 (Europe/General Specs.)	2006-2009	PCM	●	●	●	●	※
CX-7 (Europe/General Specs.)	2006-2009	TCM	●	●	●	●	※
CX-7 (Europe/General Specs.)	2006-2009	4X4	●	●	●	●	※
CX-7 (Europe/General Specs.)	2006-2009	ABS	●	●	●	●	※
CX-7 (Europe/General Specs.)	2006-2009	RCM	●	●	●	●	※
CX-7 (Europe/General Specs.)	2006-2009	IC	●	●	●	●	※
CX-7 (Europe/General Specs.)	2006-2009	GEM	●	●	●	●	※
CX-7 (Japan/General Specs.)	2006-2009	PCM	●	●	●	●	※
CX-7 (Japan/General Specs.)	2006-2009	TCM	●	●	●	●	※
CX-7 (Japan/General Specs.)	2006-2009	4X4	●	●	●	●	※
CX-7 (Japan/General Specs.)	2006-2009	ABS	●	●	●	●	※
CX-7 (Japan/General Specs.)	2006-2009	RCM	●	●	●	●	※
CX-7 (Japan/General Specs.)	2006-2009	IC	●	●	●	●	※
CX-7 (Japan/General Specs.)	2006-2009	GEM	●	●	●	●	※
CX-7 (Japan/General Specs.)	2006-2009	RVM	●	●	●	●	※
CX-7 (North America/General Specs.)	2007-2010	PCM	●	●	●	●	※
CX-7 (North America/General Specs.)	2007-2010	TCM	●	●	●	●	※
CX-7 (North America/General Specs.)	2007-2010	ABS	●	●	●	●	※
CX-7 (North America/General Specs.)	2007-2010	RCM	●	●	●	●	※
CX-7 (North America/General Specs.)	2007-2010	IC	●	●	●	●	※
CX-7 (North America/General Specs.)	2007-2010	EATC	●	●	●	●	※
CX-7 (North America/General Specs.)	2007-2010	GEM	●	●	●	●	※
CX-8	ALL	PCM	●	●	●	●	※
CX-8	ALL	TCM	●	●	●	●	※
CX-8	ALL	4X4	●	●	●	●	※
CX-8	ALL	ABS	●	●	●	●	※
CX-8	ALL	RCM	●	●	●	●	※
CX-8	ALL	IC	●	●	●	●	※
CX-8	ALL	EATC	●	●	●	●	※
CX-8	ALL	EPB	●	●	●	●	※
CX-8	ALL	AFS	●	●	●	●	※
CX-8	ALL	DSM	●	●	●	●	※
CX-8	ALL	EPS	●	●	●	●	※
CX-8	ALL	BCM	●	●	●	●	※
CX-9	ALL	PCM	●	●	●	●	※
CX-9	ALL	TCM	●	●	●	●	※
CX-9	ALL	4X4	●	●	●	●	※
CX-9	ALL	ABS	●	●	●	●	※
CX-9	ALL	RCM	●	●	●	●	※
CX-9	ALL	IC	●	●	●	●	※
CX-9	ALL	EATC	●	●	●	●	※
CX-9	ALL	EPB	●	●	●	●	※
CX-9	ALL	SCBS	●	●	●	●	※
CX-9	ALL	PSM	●	●	●	●	※
CX-9	ALL	AFS	●	●	●	●	※
CX-9	ALL	DSM	●	●	●	●	※
CX-9	ALL	EPS	●	●	●	●	※
CX-9	ALL	BCM	●	●	●	●	※
CX-9 (North America/General Specs.)	2007-2011	PCM	●	●	●	●	※
CX-9 (North America/General Specs.)	2007-2011	TCM	●	●	●	●	※
CX-9 (North America/General Specs.)	2007-2011	4X4	●	●	●	●	※
CX-9 (North America/General Specs.)	2007-2011	ABS	●	●	●	●	※
CX-9 (North America/General Specs.)	2007-2011	RCM	●	●	●	●	※
CX-9 (North America/General Specs.)	2007-2011	IC	●	●	●	●	※
CX-9 (North America/General Specs.)	2007-2011	VSM	●	●	●	●	※
CX-9 (North America/General Specs.)	2007-2011	DSM	●	●	●	●	※
CX-9 (North America/General Specs.)	2007-2011	GEM	●	●	●	●	※
DEMIO (JPN) /MAZDA2 (General)	2007	PCM	●	●	●	●	※
DEMIO (JPN) /MAZDA2 (General)	2007	TCM	●	●	●	●	※
DEMIO (JPN) /MAZDA2 (General)	2007	ABS	●	●	●	●	※
DEMIO (JPN) /MAZDA2 (General)	2007	RCM	●	●	●	●	※
DEMIO (JPN) /MAZDA2 (General)	2007	IC	●	●	●	●	※
DEMIO (JPN) /MAZDA2 (General)	2007	BCM	●	●	●	●	※
DEMIO (JPN) /MAZDA2 (General)	2007	EPS	●	●	●	●	※
DEMIO (JPN) /MAZDA2 (General)	2007	RKE	●	●	●	●	※
DEMIO (JPN) /MAZDA2 (OTHER)	ALL	PCM	●	●	●	●	※
DEMIO (JPN) /MAZDA2 (OTHER)	ALL	TCM	●	●	●	●	※
DEMIO (JPN) /MAZDA2 (OTHER)	ALL	ABS	●	●	●	●	※
DEMIO (JPN) /MAZDA2 (OTHER)	ALL	RCM	●	●	●	●	※
DEMIO (JPN) /MAZDA2 (OTHER)	ALL	IC	●	●	●	●	※
DEMIO (JPN) /MAZDA2 (OTHER)	ALL	VSM	●	●	●	●	※
DEMIO (JPN) /MAZDA2 (OTHER)	ALL	BCM	●	●	●	●	※

DEMIO (JPN) /MAZDA2 (OTHER)	ALL	EPS	●	●	●	●	※
DEMIO (JPN) /MAZDA2 (OTHER)	ALL	RKE	●	●	●	●	※
DEMIO (JPN) /VERISA (JPN) /MAZDA2 (General)	2002-2005	PCM	●	●	●	●	※
DEMIO (JPN) /VERISA (JPN) /MAZDA2 (General)	2002-2005	4X4	●	●	●	●	※
DEMIO (JPN) /VERISA (JPN) /MAZDA2 (General)	2002-2005	ABS	●	●	●	●	※
DEMIO (JPN) /VERISA (JPN) /MAZDA2 (General)	2002-2005	RCM	●	●	●	●	※
DEMIO (JPN) /VERISA (JPN) /MAZDA2 (General)	2002-2005	IC	●	●	●	●	※
DEMIO (JPN) /VERISA (JPN) /MAZDA2 (General)	2002-2005	EPS	●	●	●	●	※
DEMIO (JPN) /VERISA (JPN) /MAZDA2 (General)	2002-2005	RKE	●	●	●	●	※
DEMIO/121 DEMIO/121	1996-2000	PCM	●	●	●	●	※
DEMIO/121 DEMIO/121	1996-2000	ABS	●	●	●	●	※
DEMIO/FESTIVA MINI WAGON	1996-2000	PCM	●	●	●	●	※
DEMIO/FESTIVA MINI WAGON	1996-2000	ABS	●	●	●	●	※
Escape/Tribute	2003-2006	PCM	●	●	●	●	※
Escape/Tribute	2003-2006	ABS	●	●	●	●	※
Escape/Tribute	2003-2006	RCM	●	●	●	●	※
Escape/Tribute	2003-2006	IC	●	●	●	●	※
Escape/Tribute	2003-2006	GEM	●	●	●	●	※
Escape/Tribute/Maverick	2001-2007	PCM	●	●	●	●	※
Escape/Tribute/Maverick	2001-2007	4X4	●	●	●	●	※
Escape/Tribute/Maverick	2001-2007	ABS	●	●	●	●	※
Escape/Tribute/Maverick	2001-2007	RCM	●	●	●	●	※
Escape/Tribute/Maverick	2001-2007	IC	●	●	●	●	※
Escape/Tribute/Maverick	2001-2007	PAM	●	●	●	●	※
Escape/Tribute/Maverick	2001-2007	GEM	●	●	●	●	※
Escape/Tribute/Mariner	2008-2012	PCM	●	●	●	●	※
Escape/Tribute/Mariner	2008-2012	4X4	●	●	●	●	※
Escape/Tribute/Mariner	2008-2012	ABS	●	●	●	●	※
Escape/Tribute/Mariner	2008-2012	RCM	●	●	●	●	※
Escape/Tribute/Mariner	2008-2012	IC	●	●	●	●	※
Escape/Tribute/Mariner	2008-2012	HVAC	●	●	●	●	※
Escape/Tribute/Mariner	2008-2012	PAM	●	●	●	●	※
Escape/Tribute/Mariner	2008-2012	GEM	●	●	●	●	※
Escape/Tribute/Mariner	2008-2012	PSCM	●	●	●	●	※
Escape/Tribute/Maverick/Mariner	2005	PCM	●	●	●	●	※
Escape/Tribute/Maverick/Mariner	2005	4X4	●	●	●	●	※
Escape/Tribute/Maverick/Mariner	2005	ABS	●	●	●	●	※
Escape/Tribute/Maverick/Mariner	2005	RCM	●	●	●	●	※
Escape/Tribute/Maverick/Mariner	2005	IC	●	●	●	●	※
Escape/Tribute/Maverick/Mariner	2005	PAM	●	●	●	●	※
Escape/Tribute/Maverick/Mariner	2005	GEM	●	●	●	●	※
FAMILIA/LASER	1996-2002	PCM	●	●	●	●	※
FAMILIA/LASER	1996-2002	ABS	●	●	●	●	※
FAMILIA VAN (BV*Y12)	2007-2017	PCM	●	●	●	●	※
FAMILIA VAN (BV*Y12)	2007-2017	ABS	●	●	●	●	※
FAMILIA VAN (BV*Y12)	2007-2017	RCM	●	●	●	●	※
FAMILIA VAN (BV*Y12)	2007-2017	IC	●	●	●	●	※
FAMILIA VAN (BV*Y12)	2007-2017	ADAS	●	●	●	●	※
FAMILIA VAN (BV*Y12)	2007-2017	EPS	●	●	●	●	※
FAMILIA VAN (BV*Y12)	2007-2017	GEM	●	●	●	●	※
Fiesta/Mazda 121/Bantam	1996-2000	PCM	●	●	●	●	※
Fiesta/Mazda 121/Bantam	1996-2000	ABS	●	●	●	●	※
Fiesta/Mazda 121/Bantam	1996-2000	ECS	●	●	●	●	※
Fiesta/Mazda 121/Bantam	1996-2000	HEC	●	●	●	●	※
Fiesta/Mazda 121/Bantam	1996-2000	CSM	●	●	●	●	※
Fiesta/Mazda 121/Bantam	1996-2000	GEM	●	●	●	●	※
FLAIR/FLAIR CROSSOVER	ALL	PCM	●	●	●	●	※
FRIENDEE/FREDA/BONGO FRIENDEE	1997-2002	PCM	●	●	●	●	※
FRIENDEE/FREDA/BONGO FRIENDEE	1997-2002	TCM	●	●	●	●	※
LANTIS	1996	PCM	●	●	●	●	※
LAPUTA	1998-2002	PCM	●	●	●	●	※
LAPUTA	1998-2002	ABS	●	●	●	●	※
LAPUTA	1998-2002	RCM	●	●	●	●	※
MARVIE	1996	PCM	●	●	●	●	※
MAZDA 929	1997	PCM	●	●	●	●	※
MAZDA2 (China)	2007	PCM	●	●	●	●	※
MAZDA2 (China)	2007	ABS	●	●	●	●	※
MAZDA2 (China)	2007	RCM	●	●	●	●	※
MAZDA2 (China)	2007	IC	●	●	●	●	※
MAZDA2 (China)	2007	BCM	●	●	●	●	※
MAZDA2 (China)	2007	EPS	●	●	●	●	※
MAZDA2 (China)	2007	RKE	●	●	●	●	※

MAZDA2 (EURO STG3/4 Specs.)	2002-2006	PCM	●	●	●	●	※
MAZDA2 (EURO STG3/4 Specs.)	2002-2006	TCM	●	●	●	●	※
MAZDA2 (EURO STG3/4 Specs.)	2002-2006	ABS	●	●	●	●	※
MAZDA2 (EURO STG3/4 Specs.)	2002-2006	RCM	●	●	●	●	※
MAZDA2 (EURO STG3/4 Specs.)	2002-2006	IC	●	●	●	●	※
MAZDA2 (Europe)	2007-2008	PCM	●	●	●	●	※
MAZDA2 (Europe)	2007-2008	ABS	●	●	●	●	※
MAZDA2 (Europe)	2007-2008	RCM	●	●	●	●	※
MAZDA2 (Europe)	2007-2008	IC	●	●	●	●	※
MAZDA2 (Europe)	2007-2008	VSM	●	●	●	●	※
MAZDA2 (Europe)	2007-2008	BCM	●	●	●	●	※
MAZDA2 (Europe)	2007-2008	EPS	●	●	●	●	※
MAZDA2 (Europe)	2007-2008	RKE	●	●	●	●	※
MAZDA2/DEMIO	ALL	PCM	●	●	●	●	※
MAZDA2/DEMIO	ALL	TCM	●	●	●	●	※
MAZDA2/DEMIO	ALL	4X4	●	●	●	●	※
MAZDA2/DEMIO	ALL	ABS	●	●	●	●	※
MAZDA2/DEMIO	ALL	RCM	●	●	●	●	※
MAZDA2/DEMIO	ALL	IC	●	●	●	●	※
MAZDA2/DEMIO	ALL	SCBS	●	●	●	●	※
MAZDA2/DEMIO	ALL	BCMII	●	●	●	●	※
MAZDA2/DEMIO	ALL	DSM	●	●	●	●	※
MAZDA2/DEMIO	ALL	EPS	●	●	●	●	※
MAZDA3 (China/General)	2007	PCM	●	●	●	●	※
MAZDA3 (China/General)	2007	ABS	●	●	●	●	※
MAZDA3 (China/General)	2007	RCM	●	●	●	●	※
MAZDA3 (China/General)	2007	IC	●	●	●	●	※
MAZDA3 (China/General)	2007	EATC	●	●	●	●	※
MAZDA3 (China/General)	2007	GEM	●	●	●	●	※
MAZDA3 (China/General)	2007	RKE	●	●	●	●	※
MAZDA3 (EURO STG3/4/5 And General Specs.)	2003-2006	PCM	●	●	●	●	※
MAZDA3 (EURO STG3/4/5 And General Specs.)	2003-2006	ABS	●	●	●	●	※
MAZDA3 (EURO STG3/4/5 And General Specs.)	2003-2006	RCM	●	●	●	●	※
MAZDA3 (EURO STG3/4/5 And General Specs.)	2003-2006	IC	●	●	●	●	※
MAZDA3 (EURO STG3/4/5 And General Specs.)	2003-2006	EATC	●	●	●	●	※
MAZDA3 (EURO STG3/4/5 And General Specs.)	2003-2006	GEM	●	●	●	●	※
MAZDA3 (EURO STG3/4/5 And General Specs.)	2003-2006	RKE	●	●	●	●	※
MAZDA3 (North America/General)	2004-2012	PCM	●	●	●	●	※
MAZDA3 (North America/General)	2004-2012	ABS	●	●	●	●	※
MAZDA3 (North America/General)	2004-2012	RCM	●	●	●	●	※
MAZDA3 (North America/General)	2004-2012	IC	●	●	●	●	※
MAZDA3 (North America/General)	2004-2012	GEM	●	●	●	●	※
MAZDA3/AXELA	ALL	PCM	●	●	●	●	※
MAZDA3/AXELA	ALL	TCM	●	●	●	●	※
MAZDA3/AXELA	ALL	ABS	●	●	●	●	※
MAZDA3/AXELA	ALL	RCM	●	●	●	●	※
MAZDA3/AXELA	ALL	IC	●	●	●	●	※
MAZDA3/AXELA	ALL	EATC	●	●	●	●	※
MAZDA3/AXELA	ALL	EPB	●	●	●	●	※
MAZDA3/AXELA	ALL	AFS	●	●	●	●	※
MAZDA3/AXELA	ALL	DSM	●	●	●	●	※
MAZDA3/AXELA	ALL	EPS	●	●	●	●	※
MAZDA3/AXELA	ALL	BCMII	●	●	●	●	※
MAZDA5 (EURO STG3/4/5 And General Specs.)/ I-MAX	2005-2007	PCM	●	●	●	●	※
MAZDA5 (EURO STG3/4/5 And General Specs.)/ I-MAX	2005-2007	ABS	●	●	●	●	※
MAZDA5 (EURO STG3/4/5 And General Specs.)/ I-MAX	2005-2007	RCM	●	●	●	●	※
MAZDA5 (EURO STG3/4/5 And General Specs.)/ I-MAX	2005-2007	IC	●	●	●	●	※
MAZDA5 (EURO STG3/4/5 And General Specs.)/ I-MAX	2005-2007	EATC	●	●	●	●	※
MAZDA5 (EURO STG3/4/5 And General Specs.)/ I-MAX	2005-2007	GEM	●	●	●	●	※
MAZDA5 (EURO STG3/4/5 And General Specs.)/ I-MAX	2005-2007	RKE	●	●	●	●	※
MAZDA5 (North America Specs.)	2006-2010	PCM	●	●	●	●	※
MAZDA5 (North America Specs.)	2006-2010	TCM	●	●	●	●	※
MAZDA5 (North America Specs.)	2006-2010	ABS	●	●	●	●	※
MAZDA5 (North America Specs.)	2006-2010	RCM	●	●	●	●	※
MAZDA5 (North America Specs.)	2006-2010	IC	●	●	●	●	※

MAZDA5(North America Specs.)	2006-2010	EATC	●	●	●	●	※
MAZDA5(North America Specs.)	2006-2010	TPM	●	●	●	●	※
MAZDA5(North America Specs.)	2006-2010	EPS	●	●	●	●	※
MAZDA5(North America Specs.)	2006-2010	GEM	●	●	●	●	※
MAZDA6(China)	2007	PCM	●	●	●	●	※
MAZDA6(China)	2007	TCM	●	●	●	●	※
MAZDA6(China)	2007	ABS	●	●	●	●	※
MAZDA6(China)	2007	RCM	●	●	●	●	※
MAZDA6(China)	2007	IC	●	●	●	●	※
MAZDA6(China)	2007	EATC	●	●	●	●	※
MAZDA6(China)	2007	BCM	●	●	●	●	※
MAZDA6(China)	2007	EPS	●	●	●	●	※
MAZDA6(China)	2007	RKE	●	●	●	●	※
MAZDA6(EURO STG3/4 And General)	2002-2005	PCM	●	●	●	●	※
MAZDA6(EURO STG3/4 And General)	2002-2005	4X4	●	●	●	●	※
MAZDA6(EURO STG3/4 And General)	2002-2005	ABS	●	●	●	●	※
MAZDA6(EURO STG3/4 And General)	2002-2005	RCM	●	●	●	●	※
MAZDA6(EURO STG3/4 And General)	2002-2005	IC	●	●	●	●	※
MAZDA6(EURO STG3/4 And General)	2002-2005	GEM	●	●	●	●	※
MAZDA6(EURO STG3/4 And General)	2002-2005	RKE	●	●	●	●	※
MAZDA6(GH, After Facelift)/ATENZA	ALL	PCM	●	●	●	●	※
MAZDA6(GH, After Facelift)/ATENZA	ALL	TCM	●	●	●	●	※
MAZDA6(GH, After Facelift)/ATENZA	ALL	ABS	●	●	●	●	※
MAZDA6(GH, After Facelift)/ATENZA	ALL	RCM	●	●	●	●	※
MAZDA6(GH, After Facelift)/ATENZA	ALL	IC	●	●	●	●	※
MAZDA6(GH, After Facelift)/ATENZA	ALL	EATC	●	●	●	●	※
MAZDA6(GH, After Facelift)/ATENZA	ALL	BCM	●	●	●	●	※
MAZDA6(GH, After Facelift)/ATENZA	ALL	RKE	●	●	●	●	※
MAZDA6(GH, Before Facelift)	2007-2008	PCM	●	●	●	●	※
MAZDA6(GH, Before Facelift)	2007-2008	ABS	●	●	●	●	※
MAZDA6(GH, Before Facelift)	2007-2008	RCM	●	●	●	●	※
MAZDA6(GH, Before Facelift)	2007-2008	IC	●	●	●	●	※
MAZDA6(GH, Before Facelift)	2007-2008	EATC	●	●	●	●	※
MAZDA6(GH, Before Facelift)	2007-2008	BCM	●	●	●	●	※
MAZDA6(GH, Before Facelift)	2007-2008	EPS	●	●	●	●	※
MAZDA6(GH, Before Facelift)	2007-2008	RKE	●	●	●	●	※
MAZDA6(Middle East/General)	2009-2010	PCM	●	●	●	●	※
MAZDA6(Middle East/General)	2009-2010	TCM	●	●	●	●	※
MAZDA6(Middle East/General)	2009-2010	ABS	●	●	●	●	※
MAZDA6(Middle East/General)	2009-2010	RCM	●	●	●	●	※
MAZDA6(Middle East/General)	2009-2010	IC	●	●	●	●	※
MAZDA6(Middle East/General)	2009-2010	EATC	●	●	●	●	※
MAZDA6(Middle East/General)	2009-2010	BCM	●	●	●	●	※
MAZDA6(Middle East/General)	2009-2010	RKE	●	●	●	●	※
MAZDA6(North America/General)	2003-2010	PCM	●	●	●	●	※
MAZDA6(North America/General)	2003-2010	TCM	●	●	●	●	※
MAZDA6(North America/General)	2003-2010	ABS	●	●	●	●	※
MAZDA6(North America/General)	2003-2010	RCM	●	●	●	●	※
MAZDA6(North America/General)	2003-2010	IC	●	●	●	●	※
MAZDA6(North America/General)	2003-2010	EATC	●	●	●	●	※
MAZDA6(North America/General)	2003-2010	BCM	●	●	●	●	※
MAZDA6(North America/General)	2003-2010	RKE	●	●	●	●	※
MAZDA6/ATENZA	ALL	PCM	●	●	●	●	※
MAZDA6/ATENZA	ALL	TCM	●	●	●	●	※
MAZDA6/ATENZA	ALL	ABS	●	●	●	●	※
MAZDA6/ATENZA	ALL	RCM	●	●	●	●	※
MAZDA6/ATENZA	ALL	IC	●	●	●	●	※
MAZDA6/ATENZA	ALL	EATC	●	●	●	●	※
MAZDA6/ATENZA	ALL	EPB	●	●	●	●	※
MAZDA6/ATENZA	ALL	DSM	●	●	●	●	※
MAZDA6/ATENZA	ALL	EPS	●	●	●	●	※
MAZDA6/ATENZA	ALL	BCM	●	●	●	●	※
Millenia	1997-2001	PCM	●	●	●	●	※
Millenia	1997-2001	ABS	●	●	●	●	※
MILLENNIA/EUNOS 800	1998-2002	PCM	●	●	●	●	※
MILLENNIA/EUNOS 800	1998-2002	ABS	●	●	●	●	※
MPV(Europe/General)	1996-2004	PCM	●	●	●	●	※
MPV(Europe/General)	1996-2004	ABS	●	●	●	●	※
MPV(Europe/General)	1996-2004	FFH	●	●	●	●	※
MPV(JPN/General)	1999-2004	PCM	●	●	●	●	※
MPV(JPN/General)	1999-2004	TCM	●	●	●	●	※
MPV(JPN/General)	1999-2004	ABS	●	●	●	●	※

MPV(North America/General)	1997-2005	PCM	●	●	●	●	※
MPV(North America/General)	1997-2005	TCM	●	●	●	●	※
MPV(North America/General)	1997-2005	ABS	●	●	●	●	※
MPV/Mazda8(JPN/General)	2006-2013	PCM	●	●	●	●	※
MPV/Mazda8(JPN/General)	2006-2013	TCM	●	●	●	●	※
MPV/Mazda8(JPN/General)	2006-2013	4X4	●	●	●	●	※
MPV/Mazda8(JPN/General)	2006-2013	ABS	●	●	●	●	※
MPV/Mazda8(JPN/General)	2006-2013	RCM	●	●	●	●	※
MPV/Mazda8(JPN/General)	2006-2013	IC	●	●	●	●	※
MPV/Mazda8(JPN/General)	2006-2013	GEM	●	●	●	●	※
MPV/Mazda8(JPN/General)	2006-2013	RKE	●	●	●	●	※
MX-5	1997-2000	PCM	●	●	●	●	※
MX-5	1997-2000	ABS	●	●	●	●	※
MX-5(Europe/General Specs.)	2005-2008	PCM	●	●	●	●	※
MX-5(Europe/General Specs.)	2005-2008	TCM	●	●	●	●	※
MX-5(Europe/General Specs.)	2005-2008	ABS	●	●	●	●	※
MX-5(Europe/General Specs.)	2005-2008	RCM	●	●	●	●	※
MX-5(Europe/General Specs.)	2005-2008	IC	●	●	●	●	※
MX-5(Europe/General Specs.)	2005-2008	RKE	●	●	●	●	※
MX-5(North America/General Specs.)	2006-2010	PCM	●	●	●	●	※
MX-5(North America/General Specs.)	2006-2010	TCM	●	●	●	●	※
MX-5(North America/General Specs.)	2006-2010	ABS	●	●	●	●	※
MX-5(North America/General Specs.)	2006-2010	RCM	●	●	●	●	※
MX-5(North America/General Specs.)	2006-2010	IC	●	●	●	●	※
MX-5(North America/General Specs.)	2006-2010	RKE	●	●	●	●	※
MX-5/ROADSTER	ALL	PCM	●	●	●	●	※
MX-5/ROADSTER	ALL	TCM	●	●	●	●	※
MX-5/ROADSTER	ALL	ABS	●	●	●	●	※
MX-5/ROADSTER	ALL	RCM	●	●	●	●	※
MX-5/ROADSTER	ALL	IC	●	●	●	●	※
MX-5/ROADSTER	ALL	EATC	●	●	●	●	※
MX-5/ROADSTER	ALL	BCMII	●	●	●	●	※
MX-5/ROADSTER	ALL	EPS	●	●	●	●	※
MX-5 MIATA	1997-2005	PCM	●	●	●	●	※
MX-5 MIATA	1997-2005	ABS	●	●	●	●	※
PREMACY	1999-2003	PCM	●	●	●	●	※
PREMACY	1999-2003	ABS	●	●	●	●	※
PREMACY/MAZDA5	ALL	PCM	●	●	●	●	※
PREMACY/MAZDA5	ALL	TCM	●	●	●	●	※
PREMACY/MAZDA5	ALL	ABS	●	●	●	●	※
PREMACY/MAZDA5	ALL	RCM	●	●	●	●	※
PREMACY/MAZDA5	ALL	IC	●	●	●	●	※
PREMACY/MAZDA5	ALL	EATC	●	●	●	●	※
PREMACY/MAZDA5	ALL	BCMII	●	●	●	●	※
PREMACY/MAZDA5	ALL	EPS	●	●	●	●	※
PREMACY/MAZDA5	ALL	RKE	●	●	●	●	※
PREMACY/MAZDA5(Japan/General Specs.)	2005-2007	PCM	●	●	●	●	※
PREMACY/MAZDA5(Japan/General Specs.)	2005-2007	TCM	●	●	●	●	※
PREMACY/MAZDA5(Japan/General Specs.)	2005-2007	ABS	●	●	●	●	※
PREMACY/MAZDA5(Japan/General Specs.)	2005-2007	RCM	●	●	●	●	※
PREMACY/MAZDA5(Japan/General Specs.)	2005-2007	IC	●	●	●	●	※
PREMACY/MAZDA5(Japan/General Specs.)	2005-2007	EATC	●	●	●	●	※
PREMACY/MAZDA5(Japan/General Specs.)	2005-2007	EPS	●	●	●	●	※
PREMACY/MAZDA5(Japan/General Specs.)	2005-2007	GEM	●	●	●	●	※
PREMACY/MAZDA5(Japan/General Specs.)	2005-2007	RKE	●	●	●	●	※
PREMACY/IXION	1999-2002	PCM	●	●	●	●	※
PREMACY/IXION	1999-2002	ABS	●	●	●	●	※
PROBE/MX-6	1996-1997	PCM	●	●	●	●	※
PROCEED	1996	PCM	●	●	●	●	※
PROTEGE	1997-2003	PCM	●	●	●	●	※
PROTEGE	1997-2003	ABS	●	●	●	●	※
Ranger/Mazda B-Series/Courier	1996-2011	PCM	●	●	●	●	※
Ranger/Mazda B-Series/Courier	1996-2011	4X4	●	●	●	●	※
Ranger/Mazda B-Series/Courier	1996-2011	ABS	●	●	●	●	※
Ranger/Mazda B-Series/Courier	1996-2011	RCM	●	●	●	●	※
Ranger/Mazda B-Series/Courier	1996-2011	IC	●	●	●	●	※
Ranger/Mazda B-Series/Courier	1996-2011	GEM	●	●	●	●	※
Ranger/Mazda B-Series/Troller	2011-2019	PCM	●	●	●	●	※
Ranger/Mazda B-Series/Troller	2011-2019	TCM	●	●	●	●	※
Ranger/Mazda B-Series/Troller	2011-2019	ABS	●	●	●	●	※
Ranger/Mazda B-Series/Troller	2011-2019	RCM	●	●	●	●	※
Ranger/Mazda B-Series/Troller	2011-2019	IPC	●	●	●	●	※

Ranger/Mazda B-Series/Troller	2011-2019	PAM	●	●	●	●	※
Ranger/Mazda B-Series/Troller	2011-2019	BCMII	●	●	●	●	※
Ranger/Mazda B-Series/Troller	2011-2019	DDM	●	●	●	●	※
Ranger/Mazda B-Series/Troller	2011-2019	PSCM	●	●	●	●	※
Ranger/Mazda B-Series/Troller	2011-2019	PDM	●	●	●	●	※
ROADSTER/MX-5(Japan/General Specs.)	2005-2008	PCM	●	●	●	●	※
ROADSTER/MX-5(Japan/General Specs.)	2005-2008	TCM	●	●	●	●	※
ROADSTER/MX-5(Japan/General Specs.)	2005-2008	ABS	●	●	●	●	※
ROADSTER/MX-5(Japan/General Specs.)	2005-2008	RCM	●	●	●	●	※
ROADSTER/MX-5(Japan/General Specs.)	2005-2008	IC	●	●	●	●	※
ROADSTER/MX-5(Japan/General Specs.)	2005-2008	RKE	●	●	●	●	※
RX-8(Europe/General/Japan Specs.)	2003-2008	PCM	●	●	●	●	※
RX-8(Europe/General/Japan Specs.)	2003-2008	TCM	●	●	●	●	※
RX-8(Europe/General/Japan Specs.)	2003-2008	ABS	●	●	●	●	※
RX-8(Europe/General/Japan Specs.)	2003-2008	RCM	●	●	●	●	※
RX-8(Europe/General/Japan Specs.)	2003-2008	IC	●	●	●	●	※
RX-8(Europe/General/Japan Specs.)	2003-2008	EPS	●	●	●	●	※
RX-8(Europe/General/Japan Specs.)	2003-2008	RKE	●	●	●	●	※
RX-8(North America Specs.)	2004-2010	PCM	●	●	●	●	※
RX-8(North America Specs.)	2004-2010	TCM	●	●	●	●	※
RX-8(North America Specs.)	2004-2010	ABS	●	●	●	●	※
RX-8(North America Specs.)	2004-2010	RCM	●	●	●	●	※
RX-8(North America Specs.)	2004-2010	IC	●	●	●	●	※
RX-8(North America Specs.)	2004-2010	TPM	●	●	●	●	※
RX-8(North America Specs.)	2004-2010	EPS	●	●	●	●	※
RX-8(North America Specs.)	2004-2010	RKE	●	●	●	●	※
RX-8(North America Specs.)	2004-2010	SASM	●	●	●	●	※
SCRUM	1999-2005	PCM	●	●	●	●	※
SCRUM	1999-2005	ABS	●	●	●	●	※
SCRUM	1999-2005	RCM	●	●	●	●	※
SENTIA	1997	PCM	●	●	●	●	※
Titan	2002	PCM	●	●	●	●	※
TITAN(Isuzu OEM)	2004-2018	PCM	●	●	●	●	※
TITAN(Isuzu OEM)	2004-2018	TCM	●	●	●	●	※
TITAN(Isuzu OEM)	2004-2018	ABS	●	●	●	●	※
TITAN(Isuzu OEM)	2004-2018	RCM	●	●	●	●	※
TITAN(Isuzu OEM)	2004-2018	GEM	●	●	●	●	※
TITAN(Isuzu OEM)	2004-2018	RKE	●	●	●	●	※
TITAN DASH	2000-2004	PCM	●	●	●	●	※
TITAN DASH	2000-2004	TCM	●	●	●	●	※
VX-1	ALL	PCM	●	●	●	●	※
VX-1	ALL	TCM	●	●	●	●	※
VX-1	ALL	ABS	●	●	●	●	※
VX-1	ALL	RCM	●	●	●	●	※
VX-1	ALL	IC	●	●	●	●	※
VX-1	ALL	BCMII	●	●	●	●	※
VX-1	ALL	EPS	●	●	●	●	※
XEDOS9	1996-2000	PCM	●	●	●	●	※
XEDOS9	1996-2000	ABS	●	●	●	●	※
626/626 WAGON/TELSTAR	1997-2001	PCM	●	●	●	●	※
626/626 WAGON/TELSTAR	1997-2001	ABS	●	●	●	●	※

System List

4X4(4X4 Control Module)
ABS(Anti-Lock Braking System)
ADAS(Advanced Driver Assistance System)
AFS(Adaptive Front Lighting System)
BCMII(Body Control Module)
CSM(Security Module)
DDM(Drivers Door Module)
DSM(Driver's Seat Module)
EATC(Electronic Automatic Temperature Control)
ECS(Electronic Crash Sensor)
EPB(Electronic Parking Brake)
EPS(Electronic-Controlled Power Steering)
ESOF(Electronic Shift On The Fly)
FFH(Fuel Fired Coolant Heating Module)
GEM(Generic Electronic Module)
HEC(Hybrid Electronic Cluster)
HVAC(Heating Ventilation Air Conditioning)
HV-ECU(Hybrid Vehicle Electronic Control Unit)
IC(Instrument Cluster)

IPC(Instrument Panel Control Module)
PAM(Parking Aid Module)
PCM(Powertrain Control Module)
PDM(Passenger Front Door Module)
PSCM(Power Steering Control Module)
PSM(Parking Sensor Module)
RCM(Restraint Control Module)
RKE(Remote Keyless Entry)
RVM(Rear Vehicle Monitoring)
SASM(Steering Angle Sensor Module)
SCBS(Smart City Brake Support)
TCM(Transmission Control Module)
TPM(Tire Pressure Monitor)
VSM(Vehicle Security Module)

MAZDA DPF Function List(Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Model	DPF
AXELA / MAZDA3	※
BONGO / BONGO BRAUNY / SPECTRON	※
CX-3	※
CX-5	※
CX-7 (Europe / General Specs.)	※
CX-8	※
CX-9 (North America / General Specs.)	※
DEMIO (JPN) / MAZDA2 (OTHER)	※
DEMIO (JPN) / VERISA (JPN) / MAZDA2 (General)	※
DEMIO / 121 DEMIO / 121	※
DEMIO / FESTIVA MINI WAGON	※
FAMILIA / LASER	※
MAZDA2 / DEMIO	※
MAZDA3 (EURO STG3/4/5 And General Specs.)	※
MAZDA3 / AXELA	※
MAZDA3/ AXELA	※
MAZDA5 (EURO STG3/4/5 And General Specs.)/I-MAX	※
MAZDA6 (EURO STG3/4 And General)	※
MAZDA6 (GH, After Facelift) / ATENZA	※
MAZDA6 (GH, Before Facelift)	※
MAZDA6 (North America / General)	※
MAZDA6 / ATENZA	※
MAZDA6/ ATENZA	※
MPV (North America / General)	※
MX-5	※
MX-5 (North America / General Specs.)	※
MX-5 MIATA	※
Millenia	※
PREMACY	※
PREMACY / MAZDA5	※
PROTEGE	※
Ranger / Mazda B-Series / Troller	※
Titan	※
XEDOS9	※

DPF Function List

Diesel Particulate Filter

MAZDA ECM Function List(Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Model	ECM
AXELA / MAZDA3	※
BONGO / BONGO BRAUNY / SPECTRON	※
BT-50 / Ranger	※
CX-3	※
CX-5	※
CX-7 (Europe / General Specs.)	※
CX-8	※
CX-9 (North America / General Specs.)	※
DEMIO (JPN) / VERISA (JPN) / MAZDA2 (General)	※
DEMIO / 121 DEMIO / 121	※
DEMIO / FESTIVA MINI WAGON	※
FAMILIA / LASER	※
MAZDA2 (Europe)	※
MAZDA2 / DEMIO	※
MAZDA3 (EURO STG3/4/5 And General Specs.)	※
MAZDA3 / AXELA	※
MAZDA3/ AXELA	※
MAZDA5 (EURO STG3/4/5 And General Specs.)/I-MAX	※
MAZDA6 (EURO STG3/4 And General)	※
MAZDA6 (GH, After Facelift) / ATENZA	※
MAZDA6 (GH, Before Facelift)	※
MAZDA6 (North America / General)	※
MAZDA6 / ATENZA	※
MAZDA6/ ATENZA	※
MPV (North America / General)	※
MX-5	※
MX-5 (North America / General Specs.)	※
MX-5 MIATA	※
Millenia	※
PREMACY	※
PROTEGE	※
Ranger / Mazda B-Series / Troller	※
Titan	※
XEDOS9	※

ECM Function List

Data Reset

Service Functions(PCM)

Resetting Adaptive Values

Relearn Vehicle Data

Initialization

MAZDA EPB Function List(Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Model	EPB
MAZDA6 / ATENZA	※

EPB Function List

Brake Pad Replacement

MAZDA ETC Function List(Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Model	ETC
(All MY05) Escape/Tribute/Maverick/Mariner	※
626 / 626 WAGON / TELSTAR	※
ATENZA (JPN) / MAZDA6 (General)	※
AXELA / MAZDA3	※
BONGO / BONGO BRAWNY / SPECTRON	※
BT-50 / Ranger	※
Biante(Japan)	※
CX-7 (Europe / General Specs.)	※
Escape / Tribute / Maverick	※
Escape /Tribute / Mariner	※
Fiesta / Mazda 121 / Bantam	※
MAZDA2 (China)	※
MAZDA2 (EURO STG3/4 Specs.)	※
MAZDA2 (Europe)	※
MAZDA3 (China / General)	※
MAZDA3 (EURO STG3/4/5 And General Specs.)	※
MAZDA5 (EURO STG3/4/5 And General Specs.)/I-MAX	※
MAZDA6 (China)	※
MAZDA6 (EURO STG3/4 And General)	※
MAZDA6 (GH, After Facelift) / ATENZA	※
MAZDA6 (GH, Before Facelift)	※
MAZDA6 (Middle East / General)	※
MAZDA6 (North America / General)	※
PROBE / MX-6	※
Ranger / Courier / Mazda B-Series /Bravo	※
Ranger / Mazda B-Series / Courier	※
Ranger / Mazda B-Series / Troller	※

ETC Function List

ETB Check

ETB/EGR Initialization

Reset KAM

MAZDA INJ Function List(Note:For reference only)

NOTES:

● This function is supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

○ This function is not supported.

▲ This function is the new feature in this version.

Model	INJ
AXELA / MAZDA3	※
BONGO / BONGO BRAUNY / SPECTRON	※
BT-50 / Ranger	※
CX-7 (Europe / General Specs.)	※
DEMIO (JPN) / MAZDA2 (OTHER)	※
MAZDA2 (Europe)	※
MAZDA3 (EURO STG3/4/5 And General Specs.)	※
MAZDA5 (EURO STG3/4/5 And General Specs.)/I-MAX	※
MAZDA6 (EURO STG3/4 And General)	※
MAZDA6 (GH, After Facelift) / ATENZA	※
MAZDA6 (GH, Before Facelift)	※
PREMACY / MAZDA5	※
Ranger / Mazda B-Series / Troller	※

INJ Function List

Fuel Injector Correction Factors

Injector Correction Factors